



SUMMARY • FACTORY DEFAULT

LUTRON CASÉTA IN-WALL DIMMER

TAP ON 3× + HOLD 3 s • TAP 3×

Under 6 s • don't lift your finger




• 3 slow flashes → off → full on

Switches PD-5WS-DV / PD-6ANS: 2 flashes

APPLIES TO

PD-6WCL • PD-10NXD • PD-5NE • PD-3PCL

integratornotes.com/cards/004



INTEGRATOR NOTES

@integratornotes