



SUMMARY • REBOOT vs FACTORY DEFAULT

ARAKNIS AN-310-RT-4L2W ROUTER

PRESS = REBOOT

HOLD 10-15 s = FACTORY DEFAULT

Release when the status LEDs flash once

192.168.1.1 • araknis / araknis

AN-110: same • AN-300: 10 s reboot / 20 s factory (Diag LED)

integratornotes.com/cards/005

REAR



FRONT



INTEGRATOR NOTES

@integratornotes