



SUMMARY • FACTORY RESET + ACTIVATE


LUMA 820 TURRET

- 1 OPEN UTILITY PORT (2 SCREWS)
- 2 HOLD RESET 30 s • RELEASE
- 3 WAIT • CAMERA RESTARTS
- 4 NVR POE PORT > OVRC ACTIVATES IT

NO DEFAULT PASSWORD • OVRC SETS IT

Replace the utility port cover

integratornotes.com/cards/014



INTEGRATOR NOTES

@integratornotes