



SUMMARY • FACTORY RESET

RING WIRED DOORBELL PLUS

FACEPLATE OFF (BOTTOM SCREW)

HOLD SETUP 20 s • RELEASE

BLUE FLASH → WHITE CIRCLING



BLUE FLASHING = resetting



WHITE CIRCLING = setup mode



Quick press = Setup Mode only, no reset

Old owner: Remove Device in the Ring app

Or: Set Up a Device › Request Ownership (up to 15 days)

Battery models: button under the faceplate (front)
or on the back

integratornotes.com/cards/018

INTEGRATOR NOTES

@integratornotes